

FILLERS & CONNECTORS

KO KILLERS: PLASTIC KNOCKOUT FILLERS

Fits thin (1/32") and thick (1/8") wall thickness

Features:

- No tools required
- Snap in and out with ease
- Non-conductive, safer



- Part# KOK50 - 1/2" Filler (50/bag)
 Part# KOK75 - 3/4" Filler (50/bag)
 Part# KOK100 - 1" Filler (25/bag)
 Part# KOK125 - 1 1/4" Filler (25/bag)
 Part# KOK150 - 1 1/2" Filler (25/bag)
 Part# KOK200 - 2" Filler (25/bag)
 Part# KOK999 - Assorted Fillers Kit (25/bag)



RAT 500

Rapid Fire NMSC connector (100 Pack)

Suitable for all 1/2" knockouts
 Fast and Easy. No tools required

Features:

- 100/bag
- Single cables
- Two cables
- Install from outside

RAT 750

Rapid Fire NMSC connector (50 pack)

Suitable for all 3/4" knockouts
 Fast and Easy. No tools required

Features:

- 50/bag
- Single cables
- Install from outside

Part#
RAT500 1/2" Connector
RAT750 3/4" Connector



RAT750 - 3/4"	Single Cable:	8/3, 6/3
RAT500 & TT500 - 1/2"	Single Cable:	14/2, 14/3, 12/2, 12/3, 10/2, 10/3
	Two Cables:	14/2, 14/3, 12/2

TT500

NMSC Two Way 1/2" Connector (100 Pack)

Installs from inside and outside the box

Features:

- 100/bag
- Single cables
- Two cables

Part#
TT500



STUD BUDDIES

(100 Pack)

Why Square Bushing? 70%
 More cross sectional area!
 More cables, easier pulls.

- One piece
- One hand installation
- Fits all standard steel studs & punches
- Fire rated V.O.
- Faster, easier to use

Part#
SB220 - ROUND
SB240 - SQUARE



BUCKETS

Our same great connectors now available in bulk bucket form!

Part#'s

- RAT500.B2 - 1/2" Connector Qty. 200
 RAT500.B4 - 1/2" Connector Qty. 400
 TT500.B2 - 1/2" Tom 2-Way Connector Qty. 200
 TT500.B4 - 1/2" Tom 2-Way Connector Qty. 400

LEVEL JACK

HOW DOES IT WORK?

Alignment tabs reach across wood/metal studs to level low voltage outlets with A.C. boxes.

NO TAPE MEASURE • NO LEVEL REQUIRED

Available in 1/2" and 1" rise

If you're fussy about your rough-in layout, the Level Jack makes life easy. If you're not, no one will notice because you can't screw up with the Level Jack.

Just clip it on to the AC box and screw it down. No level, no tape measure, no special boxes, no special fittings required. Level Jacks fit most AC boxes.



Part#
LJ50R - 1/2" (30 pack)

