




LUMENTASK™ ACCESSORIES and FEATURES

KEY TO CONNECTOR DIAGRAMS

1. EZ-1 connects two LumenTask™ fixtures in series.

2. EZ Connectors connects two LumenTask™ fixtures with a flexible cord:

EZ-3 (3" connector) EZ-6 (6" connector)
EZ-12 (12" connector) EZ-18 (18" connector)

3. SLJR-HSW Quick-Box.
2-3/4"L x 2-1/16"H x 1-1/4"W

4. CP-6 72" cord and plug.

NOTE: EZ Connectors, SLJR-HSW and CP-6 are available in white only.

Accessing the interior of LumenTask™ without removing the fixture is easy. See Open Wide feature at bottom left.

LUMENTASK™ ACCESSORIES

EZ-1	CONNECTS TWO LUMENTASK FIXTURES DIRECTLY TOGETHER
EZ-3	3" FLEXIBLE LUMENTASK FIXTURE TO FIXTURE CONNECTOR
EZ-6	6" FLEXIBLE LUMENTASK FIXTURE TO FIXTURE CONNECTOR
EZ-12	12" FLEXIBLE LUMENTASK FIXTURE TO FIXTURE CONNECTOR
EZ-18	18" FLEXIBLE LUMENTASK FIXTURE TO FIXTURE CONNECTOR
SLJR-HSW	QUICK-BOX JUNCTION BOX FOR HARDWIRE INSTALLATION MUST BE USED WITH EZ CONNECTOR. SEE PAGE 63.
CP-6	72" CORD AND PLUG WITH MODULAR CONNECTOR
G9-120VCL	35W XENON REPLACEMENT LAMP FOR 120V LUMENTASK - G9 BASE
GL8	8" REPLACEMENT LENS FOR 8" LUMENTASK MODELS
GL16	16" REPLACEMENT LENS FOR 16" LUMENTASK MODELS
GL24	24" REPLACEMENT LENS FOR 24" LUMENTASK MODELS
GL32	32" REPLACEMENT LENS FOR 32" LUMENTASK MODELS
GL40	40" REPLACEMENT LENS FOR 40" LUMENTASK MODELS



Open Wide keeps the fixture open and your hands free to wire. By simply pressing the wiring compartment holding tab, the wiring compartment cover swings down and out and stays in position until you're ready to snap it back in its closed position and slide the lens back in place.

