

Fax (516) 279-1106


Pilot Drill - A-TAPER FOR EXTENSION

Part #	Size	List
721PD0385	3/8" X 6" A-TAPER	\$12.82

INSTRUCTIONS

- Wipe off oil or lubricant from the taper of the extension and the inner taper of the core bit.
- Insert the pilot drill into the drive extension first.
- Insert the drive extension into the core bit.
- Start drilling hole until the core bit is 3/8" deep.
- Use the ejector key to push out the pilot drill.
- Ontinue drilling the hole until the material being drilled fills the core bit interior. Approximately 3" deep.
- Break the drilled material inside the core bit with a chisel (if necessary.)
- Return to Step 6 until desired hole depth is achieved.





Description

EJECTOR KEY

Part #	Size	# Teeth	List
719CB0040	1-1/2"	6	\$127.37
719CB0050	2"	6	\$151.44
719CB0065	2-1/2"	9	\$164.17
719CB0080	3" (3-1/8")	9	\$214.77
719CB0090	3-1/2" (3-9/16")	9	\$242.27
719CB0100	4"	9	\$312.14
719CB0125	5"	12	\$416.30

All 3-1/2" Diameter Core Bits Are Now 3-9/16"

Ejector Key

Part #

722EJ0001

These Heavy Duty Rotary Hammer Core Bits are used with either Spline or SDS-MAX electric rotary hammer machines. The special alloy steel body and Tungsten Carbide withstand continuous hammering. A pilot drill bit and extension are required.







Taper Shank Extensions



Part #	Size	Shank	List
720SP0008	8"	SPLINE	\$81.14
720SP0018	18"	SPLINE	\$99.87



Part #	Size	Shank	List
720MAX008	8"	SDS-MAX	\$92.42
720MAX018	18"	SDS-MAX	\$112.94



Notice: Core Bit drilling without the use of a pilot drill bit causes excessive pressure on the taper shank system. This *can* result in breakage to the extension at the tapered end, especially between the two slots. Such jagged breaks are not considered defective and *may* not be covered under warranty.

List

\$10.35

