





### KTSL-FC4-12V-PKO BLUETOOTH WIRELESS SMART PORT LUMINAIRE CONTROLLER

### **DESCRIPTION**

Bluetooth mesh wireless screw-in low voltage fixture controller for SmartLoop system; 12V; 0-10V dimming

### **APPLICATION**

Ideal for warehouses, gymnasiums, corridors, and parking garages. Installs directly into Smart Port Gen 2 compatible Keystone products.

















### **PRODUCT FEATURES**

- For use with Smart Port Gen 2 compatible Keystone products
- Commissioned via SmartLoop mobile app for iPhone and Android
- Controlled via SmartLoop mobile app, keypad, and sensors
- Utilizes Bluetooth mesh technology for reliable and secure wireless communication
- Power outage recovery defaults to automatic on state
- Indicator LED communicates device status

### **ELECTRICAL SPECIFICATIONS**

Input Voltage	10-15VDC	
Power Consumption	<0.5W	
RF Transmit Power	8dBm	
Max 0-10V Sinking Current	10mA	
Wireless Frequency	2.4GHz	
Wireless Range (Open Air)	100ft	
Wireless Protocol	Bluetooth 4.2	


### **ENVIRONMENTAL SPECIFICATIONS**

Operating Temperature	-25°C/-13°F to 60°C/140°F
Storage Temperature	-40°C/-40°F to 80°C/176°F
Humidity	10-85%
Lifetime Rating	>100,000 hrs
Moisture and Dust Rating	IP65

### **SAFETY AND EMC COMPLIANCE**

UL/cUL	UL8750
FCC	Part 15.247

### PHYSICAL SPECIFICATIONS











# KTSL-FC4-12V-PKO BLUETOOTH WIRELESS SMART PORT LUMINAIRE CONTROLLER

### **WIRING DIAGRAMS**











## KTSL-FC4-12V-PKO BLUETOOTH WIRELESS SMART PORT LUMINAIRE CONTROLLER

#### **FACTORY RESET**

Decommissioning can be done by deleting a controller from the region, a power reset sequence, or by using the reset button for certain models.

### IN THE APP

The phone/tablet must be connected to the device through the mesh network in order for the controller to be factory reset. Otherwise, the light will simply be removed from the region in the app, and the controller will need to be factory reset using one of the other methods below.

- 1. Go to the Lights page.
- 2. Press Select and check the desired lights to decommission.
- 3. Press Delete and Confirm.

### POWER CYCLE RESET SEQUENCE

If a controller is assigned to another region, it will not appear when searching for new fixtures. Perform the below power cycle sequence to factory reset the controller.

- 1. Power *On* for 1 second, then *Off* for 10 seconds.
- 2. Power *On* for 1 second, then *Off* for 10 seconds.
- 3. Power On for 1 second, then Off for 10 seconds.
- 4. Power On for 10 seconds, then Off for 10 seconds.
- 5. Power On for 10 seconds, then Off for 10 seconds.
- 6. Turn the light back On. The device should now be decommissioned and ready to add to a region.

#### RESET BUTTON

While installed in a powered lamp, Press and Hold reset button for 3 seconds to initiate a factory reset.

### **ORDERING INFORMATION**

ORDER CODE	PACK QTY.	UPC	EASY CODE
KTSL-FC4-12V-PKO	20	843654149066	RUN-10

### **CATALOG NUMBER BREAKDOWN**

## KTSL-FC4-12V-PKO

- 1 Keystone Technologies SmartLoop
- 2 Fixture Controller
- 3 Design Style 4
- 4 Low Voltage
- **5** Pin Connection
- 6 Knock Out